



# FC Plus mobile app




**Log-in**

**Vehicles location on map**

**Vehicle tracks on map**


**First, Download the app  
FCPlus from the AppCatalog  
on your mobile device**




# FC Plus App launching mobile app




1. Launch mobile app




2. Provide Username =  
email address




3. Choose 'Continue' at  
the prompt



4. Provide Employee  
Username and password




5. The FC logo will appear  
while the app loads




# FC Plus App vehicles on map




6. App launches at the vehicle list, use the search bar to find a vehicle




7. Vehicles are listed on the screen with speed or time of last GPS




8. Display on map shows all the vehicles on a map, back arrow returns to list



9. Zoom to get more specific vehicle locations, back arrow returns to list



10. Select a vehicle from the list, scroll to show vehicle specific information



# FC Plus App vehicle tracks on map








11. To show the location of the selected vehicle on the map select 'Show Vehicle'

12. The map will zoom into the selected vehicle

13. Navigate to vehicle will zoom the map onto the vehicle

14. Select 'Show Track' will display the GPS on the map

15. Choose to display from today's or yesterday's vehicle data




# FC Plus App


## vehicle tracks on map




16. Display historical GPS locations as a connected line on the map




17. Select Choose date to display info or a specific date



18. Select a date and then select



19. Displaying as many data points available for the date selected







# FC Plus App vehicle tracks on map




14. Choose the arrow to  
open a settings window




15. App related  
information and reset  
can be found here



16. Select the user icon  
from the top of the  
settings window



16. User information,  
change password and  
sign out from here



END.